



Scan for full manual

FC-54P Quick Start Guide


This guide helps you install and use your **FC-54P** for the first time.

Go to www.kramerav.com/downloads/FC-54P to download the latest user manual and check if firmware upgrades are available.


Step 1: Check what's in the box

- ✓ **FC-54P** Ethernet Gateway
- ✓ 4 Rubber feet
- ✓ 1 Bracket set
- ✓ 1 Power supply (5V DC)
- ✓ 1 Quick start guide

Step 2: Get to know your FC-54P



#	Feature	Function
1	IR IN Sensor and LED	Sensor for IR learning, LED lights during activity
2	LINK LED	Shows the Ethernet link is active
3	GPIO/RELAY 1/ 2 LED pairs	Blue LED pair shows the activity status of port 1 and port 2: When set as GPIO, the left LED of the pair indicates active IO-P1 and right LED indicates active IO-P2 When set as RELAY, the left LED of the pair indicates active Relay-P1 and right LED indicates active Relay-P2
4	IR/RS-232 3/4 LED pairs	Blue LED pair show the activity status of port 3 and port 4: When set as RS-232, the left LED of the pair indicates Tx and right LED indicates Rx When set as IR, the left LED of the pair indicates IR-P1 Tx and right LED indicates IR-P2 Tx
5	MODE DIP-switches (Port 1 and Port 2)	Switch up (off) for GPIO, switch down (on) for Relay The default setting is port 1 GPIO (up) and port 2 Relay (down)
6	MODE DIP-switches (Port 3 and Port 4)	Switch up for RS-232, switch down for IR The default setting is port 1 RS-232 (up) and port 2 IR (down)
7	ON LED	Lights green when the unit is on



#	Feature	Function
8	Port 1/2 I/O 3-pin Terminal Block	Terminal block ports 1 and 2 connect to two GPIO ports or two Relays each
9	Port 3/4 I/O 3-pin Terminal Block	Terminal block ports 3 and 4 connect to one bidirectional RS-232 port (or RS-485, port 3 only) or two IR outputs each
10	RESET Button	Press and hold while cycling the device power to reset to factory default parameters
11	ID	Press to broadcast ID message for auto-discovery of the device
12	LAN/POE RJ-45 Connector	Connects to a PoE source (Power over Ethernet) for powering and an IP client or other controller, either directly or via a LAN
13	SERVICE Mini USB Connector	Connects to a USB power source for powering and to a PC for a local firmware upgrade
14	5V DC Connector	For extra power resiliency, connect to the 5V DC power supply, center pin positive. Not needed when the device is supplied power by PoE or a USB power source

FC-54P Function Table

Port IO Function	Terminal Block Connections			IO Port Default	TCP Default Port [P1/P2]	Blue Activity LED Pair	Comment
	G	P1	P2				
GPIO	Ground	IO ₁	IO ₂	Digital In x 2	5000	ON when IO ports are active	GPIO Analog in & Digital out via Web
Relay	Common	NO ₁	NO ₂	Normally Open x 2	5000	ON when Relay ports are active	
RS-232	Ground	Rx	Tx	9600,8,N,1	5001/2	Flashes when port is transmitting & receiving data	Other serial configurations via Web, including RS-485 for Port 3
IR	Ground	IR ₁	IR ₂		5000	ON when ports are transmitting IR data	

Key:

P1 / P2 – Port 1 / Port 2

IO₁ / IO₂ – GPIO Port 1 / GPIO Port 2

NO₁/NO₂ – Normally open Port 1 / Normally open Port 2


Tx – Transmit, Rx – Receive; 9600, 8, N, 1 – 9600 baud, 8-bits, no parity, 1 stop bit

IR₁ / IR₂ – IR Port 1 / IR Port 2

Step 3: Install the FC-54P


You can attach the rubber feet and place on a table or mount the **FC-54P** in a rack (using an optional **RK-T2B** rack mount).

You can also mount this Kramer MegaTOOLS™ next to a USB power source behind an AV device, in room ceiling area, on a desk top, wall or similar area. Fasten a bracket on each side of the device using the two M3x8 screws (supplied). Use the flat-head screws (supplied) to fix the TOOLS to the mounting surface or enable it to slide in place.



Step 4: Connect the inputs and outputs

Always switch OFF the power on each device before connecting it to your **FC-54P**. For best results, we recommend that you always use Kramer high-performance cables to connect controlled equipment to the **FC-54P**.



Step 5: Connect the power

Connect the PoE or a USB power source and/or a 5V DC power adapter to the **FC-54P** and plug it into the mains electricity.

Step 6: Configure and operate the FC-54P

Note: The **FC-54P** is shipped from the factory with DHCP enabled and a random IP address. To connect the **FC-54P** on first installation, you must identify what IP address has been automatically assigned to the **FC-54P**. To discover the IP address of **FC-54P**, use **K-LAN Configurator**, available for download from our website at www.kramerav.com.

To reset the device to its factory default settings:

1. Turn off the power to the device.
2. Press and hold the Reset button on the rear panel.
3. Turn on the power to the device while holding down the Reset button for a few seconds.
4. Release the button.
The device is reset to the factory default settings.

To browse the FC-54P Web UI (User Interface) on taking the device out of the box:

Use the default host name: **FC-54P-xxxx**, where xxxx are the last four digits of the serial number of the device.

To configure and operate the FC-54P:

1. Using the device Web UI, configure the control gateway:
 - Set DHCP or assign a static IP address
 - Associate IP port(s) with the relevant port(s)
 - Configure the relevant port parameters
2. Configure IP client connection port(s) on a Kramer control or any other control software application.
3. Set the control application to use the control gateway ports for sending and receiving control communication over the IP connections.