



LEW ELECTRIC FITTINGS COMPANY

Call Today 708.345.2075



### 612-RSS FLOOR BOX Installation Instructions

These boxes are complete upon assembly and packaged as such. This box is meant for ease of installation in a wood floor where access below the floor is available.

1. Cut a round hole 4 ¼" into finished wood floor.
2. Remove conduit openings needed in floor box with screwdriver and hammer.
3. Make conduit connections into box and pull wiring through. Affix to wiring device provided.
4. Secure flange of box to finished floor using provided wood screws.
5. To access low voltage opening, remove ½" screw plug. Snap in low voltage device (not provided) onto RJ-45 opening in mounting plate underneath low voltage screw plug. Connect low voltage wiring to device from underneath flooring. Because the line voltage device is encapsulated in the floor box, the box acts as a natural partition separating the low voltage from the line voltage. No other partition or housing is necessary for the low voltage wiring.