


CHG 518 Multiple Battery Charger

5 Unit Charger. For use with Williams Sound's WIR RX18 Receiver.



WARNING: DO NOT ATTEMPT TO CHARGE NON-RECHARGEABLE BATTERIES!

Before inserting the WIR RX18 receiver into the charger, check to make sure that each receiver has BAT AP07D NiMH batteries installed! Refer to the WIR RX18 user manual.

Instructions:

- 1.) Plug the power supply into the AC wall outlet. Plug the power connector into the rear of the CHG 518 unit (Figure B).
- 2.) Insert the WIR RX18 receiver into the charging slot as illustrated in Figure A above. The receiver(s) must be placed in the charger facing forward to make contact with charger contacts. A red LED indicator will illuminate when charging and turn green when charging is complete
 - You may charge up to 5 receiver units per CHG 518 charger.
 - It will take approximately **6 hours** to fully charge new batteries.

Note: It is safe to leave the receivers in the charger, even after the batteries are fully charged. The charger will monitor the batteries and recharge if needed.

- 3.) Piggy-back cable is provided. 3 CHG 518 receivers can be powered from one power supply TFP 043.

Troubleshooting

If no LED's light up:

1. Check that the power supply is plugged into the AC outlet.
2. Check to make sure BAT AP07D NiMH batteries are installed on the RX18 receiver.
3. Be sure the receiver is facing forward in the charger (see Figure A).

CHG 518 Multiple Battery Charger Specifications

Dimensions:	12"L x 6.25"W x 1.5"H (30.48 cm x 15.875 cm x 3.81 cm)
Weight:	1.04 lbs (.47 kg) excluding power supply
Color:	Black metal and plastic
Power Supply Input:	120 VAC
Power Supply:	100-240 VAC / 12VDC TFP 043
Unit Capacity:	5 Units – 15 Units when piggy-backed to two additional chargers
Indicators:	Individual Charging Indicators: Red LEDs
Warranty:	1 year (90 day warranty on cables and power supply)
Approvals:	WEEE, RoHS
Note:	Charging specifications are based on Williams Sound Corp. rechargeable NiMH battery, BAT AP07D

New batteries have various charge conditions, therefore, some batteries may take less time to fully charge. Charging batteries generates heat. The receivers, charger, and power supply will feel warm when charging. Do not charge batteries in a closed enclosure, such as a carry case or brief case.

NOTE: SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

Recycling Instructions



Help Williams Sound protect the environment! Please take the time to dispose of your equipment properly.

Product Recycling for Customers in the European Union:

Please do NOT dispose of your Williams Sound equipment in the household trash. Please take the equipment to an electronics recycling center; OR, return the product to the factory for proper disposal.

Battery Recycling for Customers in the European Union:

Please do NOT dispose of used batteries in the household trash. Please take the batteries to a retail or community collection point for recycling.

9/25/07



LIMITED WARRANTY

Williams Sound products are engineered, designed and manufactured under carefully controlled conditions to provide you with many years of reliable service. Williams Sound warrants the CHG 518 Multiple Battery Charger against defects in materials and workmanship for ONE (1) year. During the first year from the purchase date, we will promptly repair or replace the CHG 518 Charger.

Microphones, earphones, headphones, batteries, cables, carry cases, and all other accessory products carry a 90-day warranty.

WILLIAMS SOUND HAS NO CONTROL OVER THE CONDITIONS UNDER WHICH THIS PRODUCT IS USED. WILLIAMS SOUND, THEREFORE, DISCLAIMS ALL WARRANTIES NOT SET FORTH ABOVE, BOTH EXPRESS AND IMPLIED, WITH RESPECT TO THE CHG 518 MULTIPLE BATTERY CHARGER, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. WILLIAMS SOUND SHALL NOT BE LIABLE TO ANY PERSON OR ENTITY FOR ANY MEDICAL EXPENSES OR ANY DIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY ANY USE, DEFECT, FAILURE OR MALFUNCTION OF THE PRODUCT, WHETHER A CLAIM FOR SUCH DAMAGES IS BASED UPON WARRANTY, CONTRACT, TORT OR OTHERWISE. THE SOLE REMEDY FOR ANY DEFECT, FAILURE OR MALFUNCTION OF THE PRODUCT IS REPLACEMENT OF THE PRODUCT. NO PERSON HAS ANY AUTHORITY TO BIND WILLIAMS SOUND TO ANY REPRESENTATION OR WARRANTY WITH RESPECT TO THE CHG 518 MULTIPLE BATTERY CHARGER. UNAUTHORIZED REPAIRS OR MODIFICATIONS WILL VOID THE WARRANTY.

The exclusions and limitations set out above are not intended to, and should not be construed so as to contravene mandatory provisions of applicable law. If any part or term of this Disclaimer of Warranty is held to be illegal, unenforceable or in conflict with applicable law by a court of competent jurisdiction, the validity of the remaining portions of this Disclaimer of Warranty shall not be affected, and all rights and obligations shall be construed and enforced as if this Limited Warranty did not contain the particular part or term held to be invalid.

If you experience difficulty with your system, call Toll-Free for Customer Assistance:

1-800-843-3544 (U.S.A.) or 1-952-943-2252 (Outside the U.S.A.)

If it is necessary to return the system for service, your Customer Service Representative will give you a Return Authorization Number (RA) and shipping instructions.

Pack the system carefully and send it to:

Williams Sound Corp.

Attn: Repair Dept.

10321 West 70th Street

Eden Prairie, MN 55344



WILLIAMS SOUND®

Helping People Hear

10321 West 70th St., Eden Prairie, MN 55344 U.S.A.
800.843.3544 | 952.943.2252 | FAX: 952.943.2174
www.williamssound.com