



VIDEO FURNITURE INTERNATIONAL

Furniture Designs That Communicate

FM3 - Countdown Timer with Clock - Operating instructions

Timer Mode (HH, MM, SS)

1. Press **Reset Timer** to select timer mode
2. Turn **Knob** to set desired time
3. Press the **Start/Stop** button to start or stop the timer


Clock Mode

Setting the time:

1. Press and hold the **Clock** button to enter the set time mode
2. Turn the **Knob** to set the hours
3. Press the **Clock** button again to switch to minutes
4. Turn the **Knob** to set the minutes
5. Press the **Clock** button again to return to normal display

Red-yellow-green Display LED's

- The **Green** light comes on when the timer is started and begins to blink at the **Green** warning time
- When the **Yellow** warning time is reached, the **Green** light goes off and the **Yellow** light comes on as a warning to finish shortly or "wrap it up"
- When the timer reaches zero, the **Red** light comes on and the **Yellow** light goes off. The timer stops when the **Red** light appears
- Press the reset button to turn off the **Red** light and reset the timer
- The timer will automatically shut down after a few minutes if not being used



190 Don Hillock Drive . Aurora . Ontario . L4G 0G9

Tel: (905) 751-1459

Toll Free: (877) 834-3876

Fax: (905) 751-1488



sales@video-furn.com



www.video-furn.com