




OASISTM & OASISTM MINI Table Trough Installation Sheet



CUTOUT SIZES					
	Oasis	Oasis Mini			
Cutout Width*	8.25	8.25			
Cutout Length	29.12	14.12			
* See Cutout Detail for undercuts required for door clearance.					







Installation Instructions

- 1. Cutout table as required (see Figure 1, Cutout Sizes & Cutout Detail)
- 2. Insert OASIS™ into cutout from above and clamp into position using Clamps & thumb Screws provided. Note: Keyslots in clamps engage over T-Studs in OASIS™ and thumb screws tighten against underside of table surface. (double sided tape may be required to prevent side of Bezel from bowing when in table).
- 3. Check for smooth operation of doors and adjust in cutout if required.
- 4. OASISTM Inserts have been installed at the factory but may be repositioned in the field if desired. To reposition OASISTM Inserts remove thumb nuts & washers from rear and reposition as needed (see Figure 2).
- 5. Connect all power & data cabling as needed and check for proper operation.
- 6. Attach Outer Pan (optional) to underside of table as shown in Cutout Detail.

Innovative Power + Data Solutions



Recycled Content Information 🧶						
		Oasis B	Oasis A Powder Coat	Oasis B Powder Coat		
Post–Consumer Content		23.50%	24.30%	23.60%		
Pre-Consumer Content	7.80%	7.50%	6.10%	5.90%		
Total % qualifying toward LEED®		27.20%	27.30%	26.50%		

Recycled Content Information 🧀					
	Oasis Mini A/B	Oasis Mini A/B Powder Coat			
Post-Consumer Content		26.20%			
Pre-Consumer Content		6.50%			
Total % qualifying toward LEED®	39.70%	29.40%			