

Stowe

PushGo™

Installation Guide


Contact Technical Support Team

✉ support@purelinkav.com


☎ (201) 488-3232 Ext.2992

What's included


A iCON-T10 Touch Screen Controller




B iCON-E1 Control Port Expander




D 16 Port PoE Network Switch




D-PS 16 Port PoE Network Switch Power Supply



F VIP-CAM-30-20x Pro PTZ Camera with HDMI, USB 2.0, and LAN Output




F-PS VIP-CAM-30-20x (Powered PoE) Power Supply (Optional)




What's included


- G** RoomView-110W
Room Scheduling Panel with Dash




- G-W** RoomView-110W
Wallmount




- G-PS** RoomView-110W
Power Supply (When using WiFi)




- K** PS-610 4K60 Seamless Presentation Switcher with Dante




- K-RX** PS-610 Rx




- K-PS** PS-610 Power Supply




- L** USB-C Power Injector




- L-PS** USB-C Power Injector
Power Supply




What's included




HDMI ↔ HDMI 3M




CAT ↔ CAT 10M




USB-C ↔ HDMI 3M




USB-C ↔ USB-C 3M




USB-A ↔ USB-B 3M



Mini Phoenix RS-232 15M




Mini Phoenix ↔ 3.5mm female 7.6M




3.5mm ↔ IR Blaster 10M

1




2







***CFE: Customer Furnished Equipment**


OR



OR









Alternative input source cable options

USB-C




[CFE]




Input source power option


USB-C




[CFE]




7




8




9




10




11




Network Connection Option 1 - PoE




Network Connection Option 2 - WiFi



13



14



➔ **NEXT STEP**

Stowe Operation Guide

Scan here to access the guide.



Contact Technical Support Team

✉ support@purelinkav.com

☎ (201) 488-3232 Ext.2992