

## **INTERFACE G2 INSTALLATION**








For use with: This product fits tables 7/8" - 2" thick.

**Note:** Circuit breaker reset located inside data compartment. A licensed electrician should make the hardwire connections.

**1-** Locate and cut the hole for the Interface G2 (6.00" x 13.63" with .25" max corner radii). Insert the Interface G2 (A) into the cutout from above.



**2-** Key slots in clamp (B) engage over T-studs in Interface G2 (A) and thumb screws (C) tighten against the underside of the table. Use appropriate key slots to clamp into position (see detail A). Note: outermost key slots in clamp (B) are not used for this product.



**3-** Connect all power and data cabling as needed.

USE LOWER HOLES FOR
TABLE THICKNESSES 1 1/4" - 2"

USE LOWER HOLES FOR
TABLE THICKNESSES 7/8" - 1 1/2"

**4-** Connections for hardwire units:

Detail A

black wire – circuit hot white wire – circuit neutral green wire – circuit ground